

UPPER FRONT BUMPER KIT



P/N 2882531

APPLICATION

Verify accessory fitment at Polaris.com.

IMPORTANT


This Upper Bumper Kit cannot be used with the Hood Rack Kit (PN 2882690)

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

KIT CONTENTS

This Kit includes:



REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	Upper Bumper, LH	-
2	1	Upper Bumper, RH	-
3	1	Brace, Center	-
4*	2	Screw, Hex Flange - M8 X 1.25 X 16	7518043
5*	4	Screw, Socket Button Head - M8 X 1.25 X 16	7517767

REF	QTY	PART DESCRIPTION	PART NUMBER
6*	2	Plate, Backing	-
7*	2	Threaded Mount	-
8*	2	Screw, Torx® Pan Head - M8 X 1.25 X 100	-
	1	Instructions	9927799

Items marked (*) are included in Hardware Kit PN 2206966.

TOOLS REQUIRED

- Safety Glasses
- Socket Set, Hex Bit, Metric
- Socket Set, Metric
- Torque Wrench
- Wrench Set, Metric

IMPORTANT


Your Upper Front Bumper Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

ASSEMBLY TIME

Approximately 15 minutes


INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove plug (A) from each end of existing front bumper. Plugs will not be reused.
3. Loosely install threaded mount (7) to tapered fitting on LH upper bumper (1) using screw (8). Screw should engage only a few threads of threaded mount.




NOTE


Over-tightening screw will prevent new bumper from entering tube opening in existing bumper.




4. Fully insert threaded mount ⑦ and tapered fitting on LH upper bumper ① into existing bumper. Do not tighten screw at this time.



5. Loosely install LH upper bumper ① to existing lower bumper using two screws ⑤ and backing plate ⑥.



6. Repeat Steps 3–5 for RH upper bumper ②.
7. Loosely install center brace ③ to LH upper bumper ① and RH upper bumper ② using two screws ④.



8. Torque all eight screws to specification.

TORQUE

16 ± 2 ft. lbs. (22 ± 2 Nm)

FEEDBACK FORM

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

FEEDBACK FORM

